

Operation Instructions

- 

Fill machine with water and cleaning detergent. Always make sure the recovery tank is empty before each use.
- 

Use lever to lower squeegee onto the floor.
- 

Press to activate brush and suction switch on the machine.
- 

Attach clean pad to pad driver. Place pad driver on floor and center it underneath the scrub deck.
- 

Release the pedal and place the scrub deck onto the pad driver.
- 

Squeeze trigger on handle to attach the pad driver.
- 

Use solution knob to adjust amount of cleaning solution being dispensed.
- 


Squeeze trigger and begin moving forward to clean and dry the floor.

Shut-Down Instructions

- 


To prevent water from leaking from machine, always raise the solution knob all the way up.
- 

Raise scrub deck by pushing on foot pedal.
- 

Move forward to recover any remaining water on the floor. Then, raise squeegee lever.
- 

To remove the pad driver (to change or clean pad), power to the machine must be on and the pad driver still raised off the floor. Squeeze the trigger on the handle and quickly release the trigger. This will cause the pad driver to fall to the floor. Then turn off brush switch and vacuum switch.
- 

Empty recovery tank after each use. Remove hose from housing clip on back of machine, remove cap and let dirty water empty into mop sink.
- 

With drain hose still in mop sink, rinse recovery tank thoroughly with water. When clean and empty, attach cap and clip back onto housing.
- 

Rinse squeegee assembly with clean water and wipe with a cloth.
- 

Connect battery to charger.